

CLASSIC CORLON & CORLON IMPRESSIONS

ENGINEERED INSTALLATION SYSTEM

QUICK REFERENCE GUIDE

Installation:	Conform to AS 1884 – 1985
Types of subfloors:	Concrete – timber
Installation system:	Full spread, heat-welded seams, PU-100 Seambond
Pattern match:	No match – reverse edges (trademark to trademark)
Coving:	Readily coveable with pre-formed cove fillet
Adhesives:	SV-200 full spread
Trowel size:	1.5mm deep, 1.5mm wide, 2.5mm apart (S-891 notched steel trowel)
Special precautions:	Do not roll material face in Do not use solvent cleaners on surface If required, use a mineral turpentine to remove dried adhesive
Recommendations:	Allow to acclimatise to room temperature (18°C) Do not lay flat for any extended period of time without adhering to substrate
Weld rod:	Use matching weld rod as per colour chart

INSTALLATION INSTRUCTIONS

INITIAL PROTECTION:

Armstrong highly recommends the installed floorcovering be protected from construction site debris, dirt, soil, traffic and stains, all of which can damage the unprotected flooring.

Armstrong recommends the use of Armstrong Topgard loose laid over the floorcovering. The floorcovering must be clean, free of all debris and must be dry. Do not tape the Topgard to the surface of the floorcovering.

Responsibility for the protection of the finished work until handed over to the client should be arranged prior to installation.

As with all urethane-coated products, some coverings could cause the urethane to cloud in the presence of moisture.

TO THE INSTALLER:

Please note that if material has been cut, fitted, or installed, NO ADJUSTMENTS or CLAIMS (if any) will be considered due to the failure to comply with any of the following. Before cutting and installing Armstrong floorcoverings make sure that you:

1. Check for obvious manufacturing defects in good daylight conditions.
2. Check that the material is the correct colour, pattern and quantity ordered by the customer.
3. Material should be allowed to acclimatise to job climatic conditions for 24 hours at 18°C. Never install the material if the temperature in the room is less than 15°C as per Australian Standard AS 1884 – 1985 Section 3 – 1.
4. Use only Armstrong recommended adhesive specifically formulated for Armstrong product.
5. All rolls of Armstrong products are marked with a 'batch number'. When using more than one roll make sure the rolls have the same 'batch number'.
6. After loosely laying the first two strips, before adhering, step back and inspect the overall effect. If acceptable, then go ahead and adhere, but if there seems to be a problem or doubt of any kind then stop immediately and call the distributor or Armstrong Customer Service on **1800 632 624**.
7. Do not cut or install any damaged or defective material unless accepted, agreed and approved by all parties concerned.

PLEASE NOTE: Existing resilient flooring backing, or lining felts should **NOT BE SANDED**. These products may contain asbestos fibres that are not readily identifiable. You should note the details in the 'WARNING' panel set out later in these instructions **BEFORE YOU PROCEED ANY FURTHER**. If you have satisfied the requirement of the warning then, providing it does not conflict with any applicable laws, the following procedure is suggested to remove existing resilient floorcoverings.

The wear layer should be cut into narrow strips, being careful not to score the subfloor. The narrow strips should then be peeled from the backing by pulling or rolling around a core which will control the stripping angle and create a uniform and more constant tension. After the wear layer has been removed, the remaining felt should be scraped by using scrapers (MUST NOT SAND).

Any unevenness in the subfloor due to scraping should be levelled and smoothed using an underlayment as per manufacturers recommendations.

SUBFLOORS

The condition of the subfloor not only has an important bearing on the appearance of the finished installation, but can dramatically affect the life and serviceability of the floorcovering. It is essential, therefore, that the subfloor be dry, hard, rigid, smooth, level, clean and free of dust and grease.

CONCRETE SUBFLOORS

Concrete subfloors must be cured and completely dry. The surface must be steel trowelled to a smooth dense surface free of trowel marks, irregularities, as per Australian Standards.

Concrete slabs in contact with fill, hardcore or the ground must have a damp-proof membrane to prevent entry of moisture. Water proofing additives and curing compounds do not replace the damp-proof membrane. New slabs should dry for at least one month per 25mm thickness.

Care must be taken to ensure that the surface of the concrete is free of parting or curing compounds, oil, grease, paint, dust and any other substances, which may prevent the adhesive from forming a secure bond. The surface of the concrete must be smooth and level, completely free of cracks, holes and protrusions.

If the surface is not satisfactory it should be repaired and levelled with a cementitious underlay, applied according to manufacturers recommendations.

When curing compounds, hardeners, sealers, or parting compounds have been used, they have to be completely removed by sanding, sandblasting or grinding prior to the installation of materials as this will impair the bond of the adhesive. *A MOISTURE TEST SHOULD ALWAYS BE CARRIED OUT PRIOR TO INSTALLATION.*

HEATED SUBFLOOR

Flooring material can be installed over heated subfloors. However, it is imperative that the temperature at the surface of the slab does not exceed 28°C. Prior to the installation, heating should be turned on for a number of days to remove all traces of residual dampness that may be present in the subfloor. The heating should be turned off 48 hours prior to and during the installation and should not be turned on until 48 hours after the installation is completed, in order to allow the adhesive to set.

TIMBER SUBFLOOR

All timber subfloors must have at least 450mm of good cross ventilation under the floor to prevent distortion and movement of flooring members as well as excessive movement of underlay. New timber subfloors should be rigid, sound and constructed of seasoned timber and free from excessive cupping and warping.

Old timber subfloors should have all loose boards re-nailed and badly worn or damaged boards must be replaced. If necessary, sand floor to a level finish without undulations. Overlay subfloor with hardboard or approved fibrous cement vinyl flooring underlayment. The underlay sheets must be fastened at 75mm intervals around all sides, 10mm from edges, and at 100mm to 150mm intervals throughout the body of the board.

The sheet shall be fastened by 25mm x 2mm ring-grooved nails, or 22mm chisel point staples for hardwood subfloors and divergent point staples for softwood subfloors. Hardboard must be laid smooth side up and all joints should be staggered. All joints and any raised edges of the underlay shall be sanded smooth and level. The sanded areas must be sealed prior to the installation of the floorcovering as recommended by the manufacturer.

Underlay must be installed over structural particleboard using the adhesive and nailing fixing system specified by the underlay manufacturer.

IMPORTANT: PLEASE READ CAREFULLY BEFORE YOU START

EXISTING RESILIENT FLOORS

Armstrong recommends the removal of existing resilient floors. If this is not practical, adequate care should be taken to ensure the existing resilient floor is to an acceptable standard to receive new floorcoverings.

The existing resilient floor must be smooth (not textured, or embossed, enough to show through the final installation), completed and firmly bonded and properly installed on recommended subfloors. Existing resilient floor must not be cushioned, and must have no evidence of moisture, alkaline salts or hydrostatic pressure. Polish and other finishes should be removed from existing floorcovering by thorough stripping. Indentations and damaged areas should be replaced or repaired.

Installation over existing resilient floors reduces resistance to indentations.

NOTE: Existing resilient flooring may contain asbestos fibres, which are not really identifiable. You should note the details in the 'WARNING' panel set out later in these instructions before you carry out these steps.

ADDITIONAL OPEN TIME OF FLOORING ADHESIVE MAY BE REQUIRED TO REDUCE ENTRAPMENT OF AIR UNDER FLOORING MATERIAL WHEN LAYING OVER EXISTING RESILIENT FLOORS.

EXPANSION JOINTS

Armstrong does not recommend that resilient floorcoverings be installed across expansion joints. Various expansion joint covers are available and should be specified by the architect or agreed between the contractor and the purchaser.

JOB CONDITIONS

Job conditions should be as outlined in Australian Standard AS 1884 - 1985 - 3 - 1. Temperatures in areas to be covered should be maintained at a minimum 18°C for 48 hours prior to, during and after installation. Please note that cold subfloors have considerable influence on the open time of flooring adhesive.

SEAMING INSTRUCTIONS

HEAT WELD

- Trim off factory edge using S-33 edge trimmer or straight edge and sharp knife, from the first piece.
- Overlap the second piece by 15mm.
- After sheets are placed in adhesive and rolled with 45kg roller, scribe seam allowing for a 1mm gap using the S-83 recess scribe.
- Heat welding should only be done when adhesive is completely cured (24 hours).
- Groove seam using hand groover for small jobs and power groover for larger ones.
- For best results and to reduced risk of damage to the surface **use an Armstrong S-65 speed nozzle.**
- Set temperature setting on the hot air welder, fitted with an **S-65 speed nozzle**, to deliver enough heat to fuse weld rod to sheet. Amperage of electrical supply, length of extension cord and wire size will affect the temperature setting. Practice on a piece of scrap material until correct setting is achieved.
- Use weld rod with colours that match sheet unless specified, otherwise check roll label for correct weld rod colour selection.
- Insert weld rod into the **S-65 speed nozzle** and immediately insert the rod into the groove.
- Hold the gun at the proper angle so that the bottom of speed nozzle is parallel with the floor. A good weld will result when the rod just starts to flair on each side of the seam but does not scorch. If scorching occurs you are going too slow.
- Allow weld rod to totally cool before skiving.
- Once weld rod is cooled trim off in two passes beginning with a quarter moon (spatula) skiving knife and a trim plate. The second pass should be flush with the flooring.

- To change directions in welding, shave off excess welding rod and groove the end of the rod for approximately 20mm. Start welding from the opposite direction and continue welding until you overlap the initial grooved weld rod for approximately 20mm then proceed with skiving.

THE SECURABOND SYSTEM

- Trim one factory edge using S-33 Edge Trimmer.
- Overlap untrimmed edge of second sheet by 15mm
- Fold back the fitted sheets marking the location of the seam on the subfloor.
- Mix S-200 as per directions on the carton (1 part A to 1 part B).
- Using trowel supplied with S-200, spread 100mm of S-200 on the seam line of the subfloor.
- Spread SV-200 on the remaining field area using recommended notched trowel.
- Allow proper 'tack off' time for field adhesive (10-20 minutes, depending on atmospheric conditions) then roll material into adhesive. Lay piece with trimmed edge first.
- Using the S-83 recess scribe set for a neat fit, scribe seam. If seam is too tight or too loose it will lift off the S-8K adhesive. There should be enough pressure so that one edge will hold the other down.
- Following the scribe mark, cut seam ensuring that the Hydrocord is not ripped or burred.
- Hand roll toward the seam to force the adhesive into and through the seam.
- Skive off any burr from seam using back if S-92 knife. Clean with dampened cloth.
- Roll with 45kg roller.

WARRANTY

Product:

Armstrong warrants its regular (first quality) products to be free from manufacturing defects for five (5) years from the date of purchase. This warranty is extendable to **ten (10) years** should the recommended Armstrong engineered installation system be followed.

Installation:

Armstrong warrants the installation integrity of these products for **ten (10) years** from the date of purchase. Installation integrity means that the products are installed according to Armstrong's expressed written recommendations using the Armstrong engineered installation system.

NOTE: Vinyl flooring manufactured in Australia after January 1, 1984, **DOES NOT** contain asbestos. However, regulations, codes and directives as to the best method of handling asbestos do exist and it is the obligation of the installer to ensure that practices used are safe, without risk to health, and meet all legal requirements.

**ALL ARMSTRONG WORLD INDUSTRIES (AUSTRALIA) PTY. LTD.
FLOORCOVERINGS, ADHESIVES & ACCESSORIES ARE MANUFACTURED ASBESTOS FREE**



Do not sand, dry sweep, dry scrape, drill, saw, beadblast, or mechanically chip or pulverise existing resilient flooring, backing, lining felt or asphaltic 'cut-back' adhesives.

These products may contain either **asbestos fibres** or **crystalline silica**.

Avoid creating dust. Inhalation of such dust is a cancer and respiratory tract hazard.

Smoking by individuals exposed to asbestos fibres greatly increases the risk of serious bodily harm.

Unless positively certain that the product to be removed is a non-asbestos containing material, you must presume it contains asbestos. Regulations may require that the material be tested to determine asbestos content.

Note: Vinyl flooring manufactured in Australia after 1st January, 1984 **does not** contain asbestos.

Disclaimer – Asbestos issues

The warnings and guidance contained in these instructions in relation to the potential for asbestos in floorcovering materials are given in good faith. However, regulations, codes and directives as to the best method of handling asbestos are under continual revision. It is the obligation of the installer to ensure that practises used are safe, without risk to health, and meet all legal requirements.

Armstrong World Industries (Australia) Pty. Ltd. accepts no liability for any loss, costs, expense or injury, however incurred, arising from the presence of any asbestos in any floorcovering materials or asphaltic 'cut-back' adhesives and/or any reliance placed upon the procedures and recommended practises contained in these instructions.

Initial Care:

After installation is completed:

1. Remove all debris from floor (electrostatic mop or vacuum).
2. Damp mop.

Allow 48 hours before carrying out the following:

1. Mop using electrostatic dust mop or vacuum.
2. Damp mop or light scrub if necessary.
Scrub with a 175- 400rpm machine, red or pre-burnish pad and pH 7.0 - 8.5 neutral detergent: **(Armstrong ONCE N' DONE)**

Note: Removal of Trademark can be carried out using water and a soft cloth.

**For Further Armstrong Information
Freecall 1800 632 624
www.armstrong-aust.com.au**